

# Laser commissioning, DetDiag news

Dmitry Vishnevskiy


Hcal Operation meeting  
Sept. 1, 2014

# Overview

- Laser commissioning (HF RADDAM)
- DetDiag news
- Health runs discussion

# Laser timing (TDC)

tRawOpto-tTrig




New laser have jitter 2.4 ns


(Old laser had unstable timing and jitter)

We need to take data periodically  
To monitor a stability of the new laser


r167369: Laser TDC Timing





r187036: Laser TDC Timing




# HF Raddam data (1)



HFM shape



HFP shape



HFM and HFM have different timing with the same delay settings

# HF Raddam data (2)

R225855, HFM

Eta phi D TS:


			0	1	2	3	4	5	6	7	8	9
-30	35	1	0	2	1260	1184	210	21	0	0	0	6
-30	71	1	4	4	2	2	2	2	4	4	2	0
-32	15	1	4	4	312	292	120	0	0	0	4	4
-32	51	1	2	4	484	334	100	8	2	4	4	8
-34	35	1	4	2	710	747	104	23	10	0	2	17
-34	71	1	2	6	4	4	0	2	2	4	4	4
-36	15	1	2	4	224	157	64	0	0	0	4	2
-36	51	1	2	2	460	1260	210	36	2	8	0	8
-38	35	1	2	2	2234	2110	312	0	0	0	0	0
-38	71	1	2	4	4	4	0	0	0	4	2	4
-40	15	1	2	4	197	137	25	2	0	0	6	4
-40	51	1	2	2	434	334	70	12	6	2	2	2
-41	35	1	2	2	1260	584	64	0	2	0	2	6
-41	71	1	4	4	2	2	2	0	2	2	4	2
-30	15	2	4	4	360	410	120	0	0	0	2	2
-30	51	2	2	4	384	360	137	12	4	4	4	4
-32	35	2	2	2	1110	747	177	10	8	0	2	30
-32	71	2	4	4	2	0	2	2	2	2	4	2
-34	15	2	4	2	384	334	60	0	0	0	2	6
-34	51	2	4	2	634	897	147	30	0	0	0	15
-36	35	2	0	2	847	1622	187	36	0	0	0	2
-36	71	2	4	4	4	2	2	2	2	2	4	4
-38	15	2	2	4	240	292	54	4	0	0	2	6
-38	51	2	2	2	1184	747	114	10	0	2	6	4
-40	35	2	2	2	947	847	120	8	0	0	0	2
-40	71	2	0	2	4	4	2	2	2	2	4	2
-41	15	2	2	4	334	224	36	0	0	2	4	4
-41	51	2	2	2	660	610	74	6	2	0	0	8

R225856, HFP


Eta phi D TS:

			0	1	2	3	4	5	6	7	8	9
30	21	1	2	634	1422	560	23	0	0	0	6	8
30	57	1	2	660	1860	997	21	4	0	0	2	25
32	1	1	2	21	64	42	6	2	2	2	2	2
32	37	1	4	80	240	100	15	0	0	0	4	4
34	21	1	2	434	797	210	12	0	2	2	19	6
34	57	1	2	747	2360	747	42	4	0	0	0	38
36	1	1	2	84	100	36	4	2	0	4	4	2
36	37	1	4	360	584	110	0	0	0	4	4	8
38	21	1	2	560	847	187	27	10	2	2	4	30
38	57	1	2	1047	1734	334	0	0	0	0	0	27
40	35	1	2	157	334	100	8	0	4	4	2	2
40	71	1	2	94	137	70	4	27	6	4	4	2
41	19	1	4	684	947	254	2	0	0	2	2	8
41	55	1	2	1984	1522	272	0	0	0	0	17	10
30	1	2	4	32	30	23	4	4	2	2	2	2
30	37	2	4	130	434	120	10	0	2	2	2	0
32	21	2	2	384	584	292	6	0	0	2	10	21
32	57	2	2	84	334	197	14	2	4	2	2	6
34	1	2	4	46	147	80	6	0	0	2	4	2
34	37	2	2	484	797	224	12	0	0	2	17	4
36	21	2	4	660	797	210	0	0	0	2	4	6
36	57	2	2	1260	2360	584	15	2	0	0	0	12
38	1	2	2	27	60	21	4	4	2	2	2	2
38	37	2	2	847	1622	312	32	0	12	2	4	15
40	19	2	4	384	534	130	15	2	4	4	8	14
40	55	2	4	1110	1260	292	0	0	0	4	10	10
41	35	2	4	50	64	15	4	2	2	2	0	2
41	71	2	4	147	130	42	0	2	2	4	2	2

# Afterpules...




# HF Raddam data quality (1)




With current timing settings we don't see S1/S2 plateau, so current data can't be used for HF RADDAM analysis.

**Fine tuning of timing required**





**Phase scan needed**

**Expected plateau**




# HF Raddam data quality (2)



With old laser (big jitter) even with not adjusted timing we had some fraction of “GOOD” events

**With new laser without properly adjusted timing fraction of “GOOD” events will be ZERO**

D.Vishnevskiy







# Conclusions / todo

- Laser TDC is working now (laser jitter  $\sim 2.4$  ns)
- QADCTDC FED included in some laser configurations
- HF raddam laser timing and amplitude was preliminary adjusted
- Phase scan needed for fine tuning of timing to make data useful for analysis
- Recover laser QADC (important for Laser->Megatile analysis)
- Adjust timing and amplitude for the rest of laser configurations
- Take laser data regularly (2 times per week) as a part of health runs (important for laser stability study)

# DetDiag (1)

- New pedestal and LED reference runs:
- PED: r225529 (no missing channels)
- LED: r225538 (HFM is good now)




- HO SiPM specific histograms removed (all regular channels are SiPMs)

# DetDiag (2)

## DetDiag in DQM GUI (III)

8



- Added bad-channels-list tables as 2D elements and slightly modified source to display tables as in DetDiag

Development to migrate DetDiag from static HTML -> DQM GUI

See Aleko's presentation:

<https://indico.cern.ch/event/336768/contribution/5/material/slides/0.pdf>

D.Vishnevskiy

11

# Health runs discussion

```
*****
HCAL Health Check
*****
**All systems have been reverted back to TTC from TCDS**
#225264 -2k- Local_Multipartition/HBHEabc_Pedestal
#225265 -10k- Local_Multipartition/HBHEabc_LED
#225266 -50k- HO/LEDs
#225267 -350k- HO/Peds
#225275 -10k- HF/Pedestal
#225277 -10k- HF/LED
#225279 -5k- HF/SelfTrigger - getting stuck at random number of events... (200, 500, 1600...)
#225283 -2k- Local_Multipartition/HCALall_Pedestal
#225284 -10k- Local_Multipartition/HCALall_LED
#225287 -5k- Local_Multipartition/HCAL_all_SelfTrigger
#225291 -400k- HO/test/LED_PED
#225293 -200k- HO/SelfTrigger_40fC
#225294 -100k- HO/SelfTrigger_50fC
#225295 -100k- HO/SelfTrigger_60fC
#225296 -420k- HO/PED_IVScan
#225298 -460k- HO/LED_IVScan
```

Similar pedestal runs:  
Do we really need this?

Similar LED runs:  
Do we really need this?

Self Trigger 5k events:  
How can we use it?

Long runs:  
Do we have enough time  
to take this runs during  
interfill Period?

- We have several pedestal and LED configurations for subdetectors + multipartition  
PED and LED runs
- Laser configurations are missing
- HF afterpulse (20TS) configuration is missing
- Proper Self trigger configurations are missing

- **We need to start discussion about run types / statistics for health / stability monitoring**
- **We need to start take health runs regularly as soon as possible**